

Figure 24. - Fuel Tank




Figure 24. - Fuel Tank

| Item | Part # | Description | Notes | Q-ty |
|------|---------------------|------------------------------|--|------|
| 1 | IMZ-8.1037-10001-21 | Fuel tank with tool box assy | Not available as a set. Please see item #3 and all needed components | 1 |
| 2 | IMZ-8.1037-10001-20 | Fuel tank assy | Not available as a set. Please see item #3 and all needed components | 1 |
| 3 | IMZ-8.1037-10004-10 | Fuel tank | Must Specify Color when Ordering | 1 |
| 3 | IMZ-8.1037-10004-11 | Fuel tank with tool box | Must Specify Color when Ordering | 1 |
| 4 | IMZ-8.1037-10047 | Tank plug assy | | 1 |
| 5 | IMZ-8.103-10155 | Tank strap | | 1 |
| 6 | 6310141-10 | Kneegrips | | 2 |
| 7 | IMZ-8.1037-10022 | Vacuum valve | | 1 |
| 7 | IMZ-8.1037-10030 | Vacuum Valve - 2007 | For use on all 2007 models only | 1 |
| 8 | IMZ-8.1236-10149 | Connecting pipe | | 1 |
| 9 | IMZ-8.1236-10321 | Fuel pipe, RH carburetor | | 1 |
| 9A | IMZ-8.1236-10324 | Fuel pipe, LH carburetor | | 1 |
| 10 | IMZ-8.1236-10135 | Pipe | | 1 |
| 11 | IMZ-8.1236-10202 | T-connector | plastic | 1 |
| 12 | IMZ-8.1236-10195 | Worm clamp | | 10 |
| 13 | IMZ-8.1236-10137 | Pipe | | 2 |
| 14 | IMZ-8.1037-10063-02 | Fuel filter | | 2 |
| 15 | IMZ-8.1037-10115 | Adapter | | 1 |
| 16 | IMZ-8.1037-10127 | Adapter nut | | 1 |
| 17 | IMZ-8.1037-10136 | Washer | | 1 |
| 18 | 6310157 | Lock key | | 2 |
| 19 | 72-10183-B | Tool box key | | 1 |
| 20 | 201474-P27C | Bolt M8x1x16 | | 2 |
| 21 | 252155-P2 | Washer 8L | | 2 |
| 22 | 252005-P27C | Washer 8 | | 2 |